


## ROUTER

### PC1005U




# **OWNER'S MANUAL**

Before operating, please read this manual completely.


## FEATURES

- **I** Providing the router function of the peripheral
- **I** Providing the router function of the peripheral and the PC
- I With RS-232 interface to connect with the PC
- I With network interface to connect with the PC through the LAN or INTERNET
- **I** Connecting with 127 equipments at one time available
- Accept AC110V/AC220V/DC24V

#### **FRONT PANEL**




#### **REAR PANEL**



- 3 Setup state indicator
- 4 Interface of the network and PC
- 5 Data output interface

6 AC110V/220V switch 7 DC24V INPUT 8 AC110V/220V input jack 9 AC110V/220V FUSE

#### CONNECTION



NOTICE: To the PC and LAN could not be available at the same time.

#### **SPECIFICATIONS**

INTERFACE TO PC	1. RS-232 2. LAN 10M
INTERFACE TO PERIPHERAL	RS-485, CAT5
MAX distance of the peripheral	1000m
MAX quantity of the peripheral	127
Power Requirement	1. AC220V/110V 50/60Hz 2. DC24V
Power	<10W
Protection	AC FUSE (220V: F0.6AL, 110V: F1AL)
Outer Packing Size(mm)	(L×W×H) 555×455×185
Unit Size (mm)	(L×W×H) 484×349.5×88
Gross weight	8.3kg
Net weight	6.5kg

Specifications are subject to be changed without notice.

#### CAUTION

- When the "Power switcher" is off, please pull out the power cord from the socket. Please keep the equipment out of water.
- To reduce the risk of electric shock, do not remove the cover.
- No user parts inside. Refer servicing to qualified service personnel.

DSPPA Acoustic Technology Co., Ltd