



ACCESSORI / OPTIONALS

A SCA (144-109) Supporti per montaggio a parete per 8005T/8010T/8015T Wall bracket for 8005T/8010T/8015T

B **HK-M6** Stativo per installazione a terra

Floor stand







RAFFAELLO

MANUALE DI ISTRUZIONI INSTRUCTION MANUAL



the sound experience

ERJK

Le informazioni contenute in questo manuale sono state scrupolosamente controllate; tuttavia la ERJK s.r.l. non si assume nessuna responsabilità per eventuali inesattezze. La ERJK s.r.l. spera di aver fornito con questo manuale sufficenti informazioni sui propri prodotti.

La ERJK s.r.l. si riserva il diritto di apportare senza preavviso cambiamento e modifiche estetiche, funzionali o di design a ciascun proprio prodotto.

All information included in this operating manual have been scrupulously controlled; however ERJK s.r.l. is not responsible for eventual mistakes. ERJK s.r.l. hope with this istruction manual to have given helpful advices about products.ERJK s.r.l. has the right to amend products and pecifications without notice.



the sound experience



the sound experience

INTRODUZIONE

La serie RAFFAELLO rappresenta la linea di ingresso tra i diffusori acustici a colonna. Gli altoparlanti da 3" ¼ montati in array conferiscono alle RAFFAELLO una resa acustica particolarmente gradevole con una efficace sensazione di presenza. La risposta in frequenza, particolarmente estesa verso gli estremi della banda audio, rende le casse acustiche RAFFAELLO idonee anche per la riproduzione di brani musicali; ne scaturisce una linea particolarmente versatile, e adatta ad una grande varietà di esigenze di sonorizzazione grazie anche alla disponibilità di tre modelli, con 5, 10 o 15 altoparlanti (rispettivamente 8005T, 8010T e

PRECAUZIONI

Si raccomanda di effettuare i collegamenti tra i diffusori e gli amplificatori di potenza quando questi ultimi sono spenti.

Per il collegamento delle casse acustiche usare l'uscita dell'amplificatore: 100V.

SCHEMA CONNESSIONI

Per l'installazione del sistema seguire la seguente procedura:


- 1) rimuovere le viti di fissaggio (A) e togliere il coperchio inferiore (fig. 1)
- **2)** forare il tappo di plastica (B) e inserire il cavo (fig.2)
- **3)** eseguire i collegamenti dei fili sulla morsettiera come da esempio (fig.3): il negativo in 0 (zero) e il positivo nella potenza desiderata: 7,5W, 15W, 30W nel modello 8005T; 15W, 30W, 60W nel modello 8010T; 60W, 120W nel modello 8015T.

INTRODUCTION

The RAFFAELLO series represents a point of entry into the world of column-shaped loudspeakers. The array assembly 3 ¼" loudspeakers give the RAFFAELLO series an acoustic which is particularly pleasant and bold. The frequency response, extending towards the extremes of the audio range, makes these speaker systems suitable for the reproduction of music. Consequently, a particularly versatile series has been produced, suitable for different sound situations as it is available in three models: with 5, 10 or 15 speakers (the 8005T, 8010T and 8015T respectively).

WARNING

on the amplifier.



CONNECTION LAYOUT

To install your speaker systems, follow this procedure:

- **1)** remove the screws (A) and the bottom cover (Fig. 1);
- **2)** pierce the plastic cap (B) and insert the cable (Fig. 2);
- 3) connect the cables to the terminal board, as in the example (Fig. 3): connect the negative to the 0 (zero) and the positive to the desired output: model 8005T>7.5W, 15W and 30W; model 8010T>15W, 30W and 60W; model 8015T>60W



.RAFFAELLO SERIES	8005T	8010T	8015T
POTENZA / POWER	7,5 / 15/ 30W rms - 100V	15 / 30 / 60W rms - 100V	60 / 120W rms - 100V
SENSIBILITA' / SENSITIVITY (1W, 1m)	91 dB	95 dB	99 dB
RISPOSTA IN FREQ. / FREQ. RESPONSE	150 -16000Hz	150 -16000Hz	150 -16000Hz
ALTOPARLANTI / LOUDSPEAKERS	5 x 3"	10 x 3"	15 x 3"
PESO / WEIGHT	3,5 kg	6,2 kg	8,9 kg
DIMENSIONI / DIMENSIONS	91x89x544 mm	91x89x941 mm	91x89x1339 mm

02