


Soundweb™ London BLU-6

Wall Panel Installation Guide



BSS Audio:

8760 S. Sandy Parkway Sandy, Utah 84070 U.S.A

http://www.bssaudious.com

Tel: 801-566-8800 • Fax: 801-568-7662 Printed in China



ZM10104-01

Useful Information

v1.0 JN 09/2004

We have written this guide with the aim of helping installers and sound engineers alike to get the most out of the BLU-6. We recommend that you read this manual, particularly the section on mechanical installation, before attempting to operate the unit.


We welcome any comments or questions regarding the BLU-6 or other BSS products, and you may contact us at the address or world wide web sites given overleaf.

Installation

The BLU-6 is a wall mounted controller which, with the rotary switch, can be used to control a source selector or parameter preset bar in the main system, and with the up and down buttons alter the level of a gain object, for example.

A sticker sheet is provided with the unit, which should cover most locational requirements, The sheet covers 4 languages: English, French, German and Spanish.

The unit is mounted into a standard UK light switch wall box; and dimensions of the unit are shown below. The pitch between the fixing hole centres is 60mm. Mounting screws are provided.



Wiring

Wiring follows the standard control input wiring for a BLU-16, 32, 80, shown below. The printing on the PCB also shows the correct wiring convention. The cable used should be regular audio cable, or any quality shielded twin-core cable.

