# MCA Series Multi-Channel Amplifiers

**Operation Manual** 

February 2012

#### **IMPORTANT SAFETY INSTRUCTIONS**

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this product near water.
- 6) Clean only with dry cloth.
- 7) Do not block ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other product (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the grounding-type plug. A grounding type plug has two blades and a third grounding prong.

The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with equipment rack, cart, stand or table designed to provide adequate mechanical strength, heat dissipation and securement to the building structure.

When a cart is used, use caution when moving the cart and product combination to avoid injury from tip-over.



- 13) Unplug this product during lightning storms or when unused for long periods of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the product has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

**WARNING -** To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

**WARNING** - This product employs Safety Grounding and must be connected to a MAINS socket that is properly grounded to provide a protective eathing connection.

**Disconnect Device -** The MAINS plug is used to disconnect MAINS power and must be installed near the equipment and remain readily accessible.

**Explanation of safety related symbols -** Product labeling and the operation manual may use the internationally recognized symbols defined below to note safety messages.



**Lightning Bolt:** Hazardous Live voltages present when this unit is in operation. Do not touch terminals marked with this symbol while the unit is connected to live power.



**Exclamation Point:** Replace components (i.e. fuses) only with the values specified by the manufacturer. Failure to do so will compromise safe operation of this unit.

# **TABLE OF CONTENTS**

MCA SERIES MULTI-CHANNEL AMPLIFIERS FEATURES
FRONT PANEL
REAR PANEL6
BRIDGING9
SPECIFICATIONS10
WARRANTY 11
EC DECLARATION12
SAFETY INFORMATION 13

#### MCA MULTI-CHANNEL AMPLIFIERS


MCA Series Multi-Channel Amplifiers provide eight channels of power amplification. Model MCA 8050 delivers 50 watts/channel into 4 ohms. Model MCA 8150 delivers 150 watts/channel into 4 ohms. Channels may be bridged in pairs for higher combined wattage. MCA Series amplifiers are covered by Biamp Systems' five-year warranty.

#### **FEATURES:**


- 8 channels of 50W (MCA 8050) or 150W (MCA 8150)
- Channels may be bridged in pairs for combined power
- Balanced line-level inputs on plug-in barrier strips
- Rear panel level controls & high-pass filter switches
- Amplifier outputs on screw-terminal connectors
- Dual-color signal/peak indicators on front & rear panels
- Front panel indicators for amplifier temp/load faults
- Fan cooled with complete output/speaker protection
- Optional transformers for 25/70/100 Volt systems
- Incorporates AES recommended grounding practices
- CE marked and UL / C-UL listed
- CCC Certified
- Covered by Biamp Systems' five-year warranty

#### FRONT PANEL

#### MCA 8050 Front Panel



#### MCA 8150 Front Panel



# Signal / Peak Indicators

These 2-color LEDs indicate the signal level for each channel. When an LED is green, that channel has signal (above -30dB). When an LED is red, that channel signal is clipping (max. power).

CAUTION: Signal levels should be adjusted to avoid clipping. Clipping can cause severe distortion, over-temperature conditions, and even loudspeaker damage.

NOTE: Signal / Peak indicators will turn off during Temp / Fault conditions (see Temp / Fault Indicators below).

#### **Temp / Fault Indicators**


These red LEDs indicate over-temperature and output fault conditions for each channel. When an LED remains lit, that channel has an over-temperature condition. When an LED is flashing, that channel has an output fault condition. Either condition will temporarily de-activate the channel, causing the Signal / Peak LED to turn off as well. The channel will attempt to self-reset once the over-temperature or output fault condition is resolved.

# **On Indicator**


This green LED remains lit when AC power is applied to the unit.

#### **REAR PANEL**

#### MCA 8050 Rear Panel



#### MCA 8150 Rear Panel



#### Input

These plug-in barrier strips provide the balanced line-level inputs to the channels. For balanced connection, wire high (+), low (-), and ground (\*). For unbalanced connection, wire high (+) and ground to both (\*) & (-).

NOTE: When using a pair of channels in 'bridged' mode (see Bridge below), input signal must be connected to the <u>odd</u> numbered channel.

#### Level

These screw-driver adjustable controls determine the level of input signals allowed into the channels. Level provides a gain range from 'off' (min.) to 'unity' (max.). The Level control is factory set for -24dB of gain, which will produce maximum output power with input signal peaks of +24dBu. For best performance, first adjust the source signals for optimum (maximum) levels, then adjust the MCA Series Level controls for the desired volume.

#### Signal / Peak Indicators

These 2-color LEDs indicate the signal level for each channel. When an LED is green, that channel has signal (above -30dB). When an LED is red, that channel signal is clipping (max. power).

CAUTION: Signal levels should be adjusted to avoid clipping. Clipping can cause severe distortion, over-temperature conditions, and even loudspeaker damage.

NOTE: Signal / Peak indicators will turn off during Temp / Fault condition (see Temp / Fault Indicators on pg. 5).

#### REAR PANEL

#### **HPF**

These DIP switches provide High-Pass Filters for the input channels. High-Pass Filters are used to eliminate unnecessary lower frequencies (12dB/octave @ 125Hz) for speech and distributed speaker applications. From the factory, the High-Pass Filters are bypassed (switches up). To assign a High-Pass Filter on an input channel, move the switch to the down position.

CAUTION: To avoid output fault conditions, High-Pass Filters must be assigned on channels driving 25/70/100 Volt speaker systems (see Output below). Also, any other system equalization affecting frequencies below 125 Hz should remain flat or be used as cut-only.

#### **Bridge**

These DIP switches allow adjacent channels to Bridge together in pairs, for a higher, combined output power (see Bridging on pg. 9). Bridge disables the even numbered input, and applies the odd numbered input signal to both amplifier channels. From the factory, Bridge is bypassed (switches up). To assign Bridge to a pair of channels, move the switch to the down position.

#### **Output**

These screw terminals provide the speaker outputs from the channels. Connect the positive speaker line to the (+) terminal and the negative speaker line to the (-) terminal of the channel being used. The minimum speaker load on an individual channel is 4 ohms.

NOTE: When using a pair of channels in 'bridged' mode (see Bridge above), connect the positive speaker line to the (+) terminal of the <u>odd</u> numbered channel and the negative speaker line to the (+) terminal of the <u>even</u> numbered channel. The minimum speaker load for a bridged output is 8 ohms. Output transformers for 25/70/100 Volt speaker systems are available as an option (installation instructions are included with the output transformers).

Transformers (by model) are as follows:

TDT50 = MCA 8050 individual channels (50 Watts)

TDT100 = MCA 8050 bridged channels (100 Watts)

TDT150 = MCA 8150 individual channels (150 Watts)

TDT300 = MCA 8150 bridged channels (300 Watts)

#### **AC Power Entrance**

The switch applies AC power to the unit. The receptacle accepts the detachable AC Power Cord. The AC Power Cord is for connection to three-prong grounded AC outlets.

CAUTION: Do not remove or defeat the ground prong on the AC Power Cord, as this constitutes a shock hazard.

#### **REAR PANEL**

#### **Line Voltage Selector Switch**

Set this switch to "115" for nominal line voltages of 110-120 VAC. Set this switch to "230" for nominal line voltages of 220-240 VAC. Make sure that the appropriate fuse is installed when changing voltage selections.

#### **Fuse**


Replace Fuse with same type and value only. MCA 8050 @ 115VAC Fuse = F 10 A H 250 V MCA 8050 @ 230VAC Fuse = T 4 A L 250 V MCA 8150 @ 115VAC Fuse = F 15 A H 250 V MCA 8150 @ 230VAC Fuse = T 6.3 A L 250 V

NOTE: If the Fuse continues to blow (even after checking for proper output connections and speaker loads) the amplifier may require service.

#### BRIDGING

Bridge DIP switches allow the adjacent odd/even numbered channels to be bridged together in pairs, for a higher, combined output power (see Bridge on pg. 7). When a pair of channels are bridged, their wattage is combined, but the minimum load increases to 8 ohms (MCA 8050 = 100 watts @ 8 ohms; MCA 8150 = 300 watts @ 8 ohms). Bridge disables the even numbered input, and applies the odd numbered input signal to both amplifier channels. From the factory, Bridge is bypassed (switches up). To assign Bridge to a pair of channels, move the related switch to the down position. Connect the source signal to the odd numbered input channel, connect the positive speaker line to the (+) output terminal of the odd numbered channel, and connect the negative speaker line to the (+) output terminal of the even numbered channel (see diagram on right).

NOTE: Only adjacent odd/even numbered channels, which share a common Bridge switch, can be bridged. When channels are bridged, the minimum load is increased to 8 ohms. The negative (-) output terminals on bridged channels are <u>not</u> used (no connection).



# **SPECIFICATIONS**

# **MCA 8050 SPECIFICATIONS**

# **MCA 8150 SPECIFICATIONS**

Maximum Power Output (@ 2kHz):		Maximum Power Output (@ 2kHz):	
Individual channel into 4 ohm load Individual channel into 8 ohm load Bridged channels into 8 ohm load	50 watts/channel 30 watts/channel 100 watts	Individual channel into 4 ohm load Individual channel into 8 ohm load Bridged channels into 8 ohm load	150 watts/channel 90 watts/channel 300 watts
Signal-to-Noise Ratio (20Hz~20kHz @ rated power):	> 85dB	Signal-to-Noise Ratio (20Hz~20kHz @ rated power):	> 85dB
THD + Noise (20Hz~20kHz @ rated power):	< 0.2%	<b>THD + Noise</b> (20Hz~20kHz @ rated power):	< 0.2%
Intermodulation Distortion (SMPTE):	< 0.35%	Intermodulation Distortion (SMPTE)	< 0.35%
Frequency Response (20Hz~20kHz):	+0/-1dB	Frequency Response (20Hz~20kHz)	+0/-1dB
Input Impedance: Balanced Unbalanced	20k ohms 10k ohms	<b>Input Impedance:</b> Balanced Unbalanced	20k ohms 10k ohms
Input Sensitivity:	0.775 Vrms (0dBu)	Input Sensitivity:	0.775 Vrms (0dBu)
Channel High-Pass Filters:	12dB/octave @ 120Hz	Channel High-Pass Filters:	12dB/octave @ 120Hz
Power Requirements:	115/230VAC 50/60Hz	Power Requirements:	115/230VAC 50/60Hz
Power Consumption:	900 watts max.	Power Consumption:	1800 watts max
Dimensions: Height (2 rack spaces) Width Depth	3.5 inches (89mm) 19 inches (483mm) 15.5 inches (394mm)	<b>Dimensions:</b> Height (3 rack spaces) Width Depth	5.25 inches (133mm) 19 inches (483mm) 15.5 inches (394mm)
Weight:	30 lbs. (13.6kg)	Weight:	35 lbs. (15.9kg)
Compliance:  EU Directive	AES48-2005 Grounding & EMC practices 2002/95/EC, RoHS directive CE marked UL / C-UL listed CCC Certified	Compliance: EU Directiv	AES48-2005 Grounding & EMC practices ve 2002/95/EC, RoHS directive CE marked UL / C-UL listed CCC Certified

Biamp Systems reserves the right to make changes to performance specifications without prior notice.

#### WARRANTY

BIAMP SYSTEMS IS PLEASED TO EXTEND THE FOLLOWING 5-YEAR LIMITED WARRANTY TO THE ORIGINAL PURCHASER OF THE PROFESSIONAL SOUND EQUIPMENT DESCRIBED IN THIS MANUAL

- 1. Biamp Systems warrants to the original purchaser of new products that the product will be free from defects in material and workmanship for a period of 5 YEARS from the date of purchase from an authorized Biamp Systems dealer, subject to the terms and conditions set forth below.
- 2. If you notify Biamp during the warranty period that a Biamp Systems product fails to comply with the warranty, Biamp Systems will repair or replace, at Biamp Systems' option, the nonconforming product. As a condition to receiving the benefits of this warranty, you must provide Biamp Systems with documentation that establishes that you were the original purchaser of the products. Such evidence may consist of your sales receipt from an authorized Biamp Systems dealer. Transportation and insurance charges to and from the Biamp Systems factory for warranty service shall be your responsibility.
- 3. This warranty will be VOID if the serial number has been removed or defaced; or if the product has been altered, subjected to damage, abuse or rental usage, repaired by any person not authorized by Biamp Systems to make repairs; or installed in any manner that does not comply with Biamp Systems' recommendations.
- 4. Electro-mechanical fans, electrolytic capacitors, gooseneck microphones, cords connecting handheld microphones, hard-drives, displays, and normal wear and tear of items such as paint, knobs, handles, keypads and covers are not covered under this warranty. All server-based devices are warranted for 3 years only.
- 5. This warranty is in lieu of all other warranties, expressed or implied. Biamp Systems disclaims all other warranties, expressed or implied, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose.
- 6. The remedies set forth herein shall be the purchaser's sole and exclusive remedies with respect to any defective product.
- 7. No agent, employee, distributor or dealer of Biamp Systems is authorized to modify this warranty or to make additional warranties on behalf of Biamp Systems. Statements, representations or warranties made by any dealer do not constitute warranties by Biamp Systems. Biamp Systems shall not be responsible or liable for any statement, representation or warranty made by any dealer or other person.
- 8. No action for breach of this warranty may be commenced more than one year after the expiration of this warranty.
- 9. Biamp Systems shall not be liable for special, indirect, incidental, or consequential damages, including lost profits or loss of use arising out of the purchase, sale, or use of the products, even if Biamp Systems was advised of the possibility of such damages.

022012 585.0075.90B





# **EC Declaration of Conformity**

Biamp Systems Corporation, as manufacturer having sole responsibility, hereby declares that our delivered version of the following described product complies with the applicable provisions of the DIRECTIVES except as noted herein. In case of any alterations to the product not agreed upon and directed by Biamp Systems Corporation, this declaration is no longer valid.

Product Models: MCA 8050 and MCA 8150

Product Description: Audio Amplifiers

Applicable EC Directives: Applicable Harmonized Standards:

LVD Directive (2006/95/EC) Safety, EN 60065:2001, Seventh Edition

EMC Directive (2004/108/EC) Emissions, EN 55103-1:1996, Environment E2

Immunity, EN 55103-2:1996

# Special Considerations for Product Environment or Compliance:

- Shielded cabling must be used for system connections.
- RF interference conducted through interconnecting cabling or connectors may cause varying degrees of random signal degradation. The effect of increased noise or distortion due to this interference is typically masked by the desired signal. In no instance is operation inhibited.

#### Technical Documentation File Location and Contact:

Biamp Systems, Inc. phone: (503) 641-7287 10074 S.W. Arctic Drive fax: (503) 626-0281 Beaverton, OR USA 97005 e-mail: biamp@biamp.com

Jarry Copley

Authorized Representative:

Larry Copley, Compliance Engineer

Authorized Signature:

Issued: May, 2007

#### **SAFETY INFORMATION**

The words WARNING and CAUTION throughout the manual, and on the device, call attention to important safety information. These words have the following meanings.

WARNING: The related information alerts you to conditions that could result in serious injury or damage to property if the instructions are not followed property.

CAUTION: The related information instructs you on how to prevent damage to the equipment or how to avoid conditions that could result in minor injury if proper steps are not followed.

Product labelling and the operation manual may use the internationally recognized symbols defined below to note safety messages.



The lightning flash with arrowhead symbol, enclosed within a triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the apparatus's enclosure or at connection terminals that may be of sufficient magnitude to constitute a risk of electrical shock.



The exclamation point, enclosed within a triangle, is intended to alert the user to important installation, operation, and maintenance (servicing) instructions in the literature accompanying the apparatus.

WARNING:

TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS APPARATUS TO BAIN OR MOISTURE.

CAUTION:

Installation of this apparatus should be made by a qualified installation person and should conform to all applicable local codes.



Modification and optional equipment information referenced in this manual is for use by qualified installation and service personnel only.



CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS INSIDE

REFER SERVICING TO QUALIFIED SERVICE PERSO

# "INFORMACIÓN DE SEGURIDAD"

Las palabras PELIGRO (WARNING) y PRECAUCIÓN (CAUTION) a lo largo del manual y en el dispositivo (sistema), llaman la atención acerca de una importante información de seguridad. Estas palabras tienen los siguientes eignificados :

PELIGRO: la información relata las condiciones en que podría ser dañada seriamente la (WARNING) propiedad si no se siguen adecuadamente las instrucciones.

PRECAUCIÓN : la información que se relata te instruye en cómo prevenir daños al equipo o (CAUTION) como evitar condiciones que podrían resultar en perjuicio menor si los pasos adecuados no son seguidos correctamente.

El etiquetado del producto y el manual de operación pueden hacer uso de los simbolos reconocidos internacionalmente y cuyos mensajes estan definidos a continuación para modificar mensajes de seguridad:



El címbolo del rayo oncorrado en un triángulo pretende alertar al usuario de la presencia de un peligroso voltaje no aislado, dentro de la caja del aparato o a un terminal de conexión y que podría ser de suficiente magnitud como para constituir un grave riesgo de descarga eléctrica.



El punto de exclamación dentro de un triángulo pretende alertar al usuario de la importancia de las instrucciones de instalación, operación y mantenimiento (servicio) que acompañan al aparato.

PELIGRO

: para reducir el riesgo de fuego o una descarga electrica, no exponer este aparato a la lluvia o la humedad.

NG)

PRECAUCIÓN : la instalación de este aparato debería hacerse por una persona cualificada (CAUTION) en la instalación, y debería conformar todos los códigos locales aplicables.



La modificación y la información opcional del equipo referenciada en este manual es para ser utilizada únicamente por personal cualificado en instalación y servicio.



EN COMPONENTES DE SERVICIO EN EL

REFERIRSE ÚNICAMENTE A PERSONAL CUALIFICADO PARA SERVICIO TECNICO

# INFORMATION CONCERNANT **VOTRE SECURITE**

Les mots WARNING et CAUTION dans le manuel d'utilisation et sur les appareils attirent votre attention sur les plus importantes informations concernant votre sécurité. Ces mots ont la signification suivante:

WARNING: Ce mot vous indique les circonstances dans lesquelles vous pourriez être blessé ou endommager votre équipement si les instructions ne sont pas suivies correctement.

**CAUTION:** Ce mot vous indique comment éviter d'endommager votre matériel et comment éviter de vous blesser si vous ne suivez pas les instructions.



L'éclair se terminant en flèche dans un triangle permet de prévenir l'utilisateur voltage dangereux non isolé dans l'appareil ou d'une connexion d'une amplitue suffisante pour constituer un risque de choc électrique.



Le point d'exclamation dans un triangle permet de prévenir l'utilisateur des points importants concernant l'installation, le fonctionnement et l'entretien de l'appareil figurant dans le manuel d'utulisation.

WARNING: POUR REDUIRE LES RISQUES DE FEU OU DE CHOC ELECTRIQUE, NE PAS METTRE L'APPAREIL SOUS LA PLUIE OU DANS L'HUMIDITE.

CAUTION:L'installation de cet appareil doit être faite par un installateur qualifié et doit être en conformité avec toutes les lois locales en application.



Les informations concernant une modification ou un équipement en option dans le manuel doivent être effectué par du personnel qualifié.



#### INFORMAZIONI PER LA SICUREZZA

e parole AVVERTENZA (WARNING) e PRUDENZA (CAUTION) poste sul manuale d'uso e sul pparato richiamano la vostra attenzione su delle importanti informazioni per la vostra sicurezza. Queste parole hanno il seguente significato.

AVVERTENZA: La suddetta indicazione vi avvisa sul rischio di incorrere in danni a cos (WARNING) persone ,se le procedure d'uso e installazione non saranno seguite pre

PRUDENZA: La suddetta indicazione vi instruisce su come prevenire e ridurre al minimo, il rischio (CAUTION) di danni agli apparati e alle persone se le instruzioni saranno seguite propriamente.

Le apparecchiature e i manuali di instruzioni riporteranno la simbologia standard raffigurata qui sotto ,accompagnate dalle relative informazioni per la sicurezza.



La simbologia con il fulmine all'interno di un triangolo, intende avvisare l'utente della presenza di allo volaggio all'interno del appareochio in questione, e che il suddetto appareochio i alimonta attraverso una tonsione di rete ad alto voltaggio e che dunque si potrebbe incorrere sul rischio di una possibile scossa elettrica.



La simbologia con il punto esclamativo all'interno di un triangolo, intende avvisare l'utente di una serie di instruzioni contenute nel manuale d'uso riguardanti : operato, manutenzione e assistenza. Il suddetto manuale sarà a corredo dell'apparecchio.

PER RIDURRE IL RISCHIO DI POSSIBILI INCENDI O SCOSSE ELECTTRICHE, SCONSIGLIAMO DI ESPORRE L'APPARECCHIO ALLA PIOGGIA O ALL'UMIDITA'.

PRUDENZA: l'Installazione di questo apparato dovrà essere effettuata solo da personale (CAUTION) qualificato e il tipo di installazione dovrà essere in regola con le norme vigenti locali



Modifiche e ulteriori informazioni specificate in questo manuale sono solamente riservate al personale qualificato all'installazione.



nacessità di servizio e manutanzione rivolgeral al personale qu

#### Sicherheitshinweise

Die Bergriffe WARNUNG (engl. WARNING) und ACHTUNG (engl. CAUTION) in der Bedienungsanleitung und auf den Geräten machen auf wichtige Sicherheitsinformati aufmerksam. Diese Begriffe haben die folgende Bedeutung:

WARNUNG: Der folgende Text warmt Sie vor ernsthaften Verletzungen oder Beschädigungen, (WARNING) die aus einer fehlerhaften Bedienung bzw. Handhabung des Gerätes resultieren

ACHTUNG: Der folgende Text informiert Sie über Bedlenungshinweise zum Schutz Ihres (CAUTION) Gerätes oder weist auf mögliche Schäden hin, wenn die Bedlenungshinweise nicht beachtet werden.

Die Beschriftung der Geräte und die Bedienungsanleitungen weisen unter Umständen international bekannte Symbole auf, die die folgende Bedeutung haben:



Das Blitzsymbol im Dreieck warmt vor anliegender, nicht isolierter "gefährlicher Spannung" im Inneren oder an den Anschlüssen des Gerätes. Die Berührung der unter Spannung stehenden Teile kann zu einem elektrischen Schock führen.

Das Rufzeichen im Dreieck macht auf wichtige Installations-, Bedienungs- und Servicehinweise in der zugehörigen Bedienungsanleitung aufmerksam.

WARNUNG: Zur Minderung des Risikos von Feuer und elektrischem Schock schützen Sie das (WARNING) Gerät vor Regen und Feuchtigkeit.

ACHTUNG: Die Installation des Gerätes sollte nur durch qualifiziertes Personal durchgeführt (CAUTION) werden und muß den jeweiligen Bestimmungen entsprechen.



Die Modifikationen und die Informationen zu den optionalen Erweiterungen in Bedienungsanleitung sind nur für qualifiziertes Personal bestimmt.



#### Sikkerhedsinformation

Ordene ADVARSEL (WARNING) og FORSIGTIG (CAUTION), brugt i henholdsvis brugervejledning og på selve produktet, indikerer, at vigtig information omkring sikke Ordene betyder følgende:

ADVARSEL: Den efterfølgende information advarer Dem om forhold, der kan føre til alvorlige (WARNING) ulykker og ejendomsskader, hvis ikke vejledningen følges.

FORSIGTIG: Den efterfølgende information veijleder Dem i, hvordan De undgår skade på (CAUTION) produktet, samt undgår forhold der kan føre till mindre ulykker og ejendomss hvis ikke veijledningen følges.

Produktetiketter og brugervejledning kan indeholde de internationalt anerkendte



Trekanten med et lyn i midten har till hensigt at advare brugeren om, at produktet indeholder "farlig spændling", og at det derfor er forbundet med fare for elektrisk sted at åbne produktet.



Trekanten med udråbstegn har til hensigt at advare brugeren om, at vigtig information omkring installation, brug, service og vedligeholdelse af produktet er indeholdt i den medfølgende brugervejledning.

ADVARSEL: Med henblik på at reducere risikoen for brand eller elektrisk stød, må produktet ikke (WARNING) udsættes for regn eller fugt.

ORSIGTIG: Installation af dette produkt skal foretages af en autoriseret inst AUTION) overensstemmelse med alle anvendelige lokale retningslinler. (CAUTION)



Modifikationer samt alternativt udstyr beskrevet i denne brugervejledning er kun henvendt til kvalificerede installatører og servicepersonale.



#### VEILIGHEIDSINFORMATIE

De woorden **WAARSCHUWING** (WARNING) en **VOORZICHTIG** (CAUTION) welke in de handleiding en op het apparaat voorkomen, waarschuwen U voor belangrijke veiligheidsin Zij hebben de volgende betekenis:

WAARSCHUWING: De betreffende informatie waarschuwt U voor omstandigheden die kunnen (WARNING) leiden tot defecten of beschadigingen aan apparaten als de instructies niet volledig worden opgevolgd.

VOORZICHTIG: De betreffende informatie instrueert U hoe U defecten aan apparatuur kunt voorkomen of hoe U omstandigheden kunt vermijden die kunnen resulteren in schade als de juiste stappen niet worden opgevolgd.

Produkt informatie en handleiding hanteren onderstaande internationaal erkende symbolen om veiligheidsinstructies aan te geven.



De bliksemschicht in een driehoek wordt gebruikt om de gebruiker te atlenderen op ongeïscleerde "gevaarlijke spanning" in het apparaat of bij de aansluitklemmen, die het risico van een electrische schok kunnen geven.



Het uitroepteken in een driehoek wordt gebruikt om de gebruiker te attenderen op belangrijke installatie, gebruiks- en onderhoudsinstructies in de beschrijving die bij het apparaat hoort.

WAARSCHUWING: OM HET RISICO VAN BRAND OF EEN ELECTRISCHE SCHOK TE (WARNING) VERMIJDEN DIENT U HET APPARAAT NIET AAN VOCHT BLOOT TE STELLEN.

VOORZICHTIG: Installatie van dit apparaat dient te geschieden door gekwalificeerd persi (CAUTION) dient te geschieden conform de plaatselijke voorschriften.



Modificaties en aanvullende informatie waar in de handleiding naar wordt ven dient alleen voor gebruik door gekwalificeerd personeel.



# TURVALLISUUSTIEDOTE

Sanat VAROITUS (WARNING) ja HUOMIO (CAUTION), jotka esiintyvät manuaalissa ja itse laitteessa, ilmoittavat tärkeästä turvallisuusinformaatiosta. Näillä sanoilla on seuraava merk

Yhteydessä oleva informaatio varoittaa olosuhteista, jotka saattavat johtaa va vammoihin tai laitteen vaurioitumiseen, mikäli ohjeita ei täysin noudateta. VAROITUS:

Yhteydessä oleva informaatio neuvoo, miten laitteen vaurioituminen voidaan ehkäistä tai miten voidaan väittää olosuhteet, jotka voivat johtaa lieviin vammoihin, mikäli ohjeita ei noudateta.



Kolmion sisällä olevan nuolipäinen salama varoittaa käyttäjää laitteen sisällä tai liitännöissä olevasta erislämättömästä vaarallisesta jännitteestä, joka saattaa olla tarpeeksi suuri aiheuttaakseen sähköiskun vaaran.



Kolmion sisällä oleva huutomerkin tarkoituksena on ilmoittaa käyttäjälle tärkeistä asennusta, käyttöä tai huoltoa koskevista ohjeista laitteen mukana seuraavassa kirjallisuudessa.

ĀLĀ ALTISTA LAITETTA SATEELLE TAI KOSTEUDELLE TULIPALON JA SĀHKŌISKUN VAARAN VUOKSI.

Laitteen asentaminen tulisi jättää ammattitaitoisen henkilön suoritettavaksi ja asennuksessa tulee noudattaa kaikkia paikallisia säännöksiä.



Tässä manuaalissa oleva informaatio, joka koskee muutostöitä ja lisälaitteita, on tarkoitettu vain ammattitaitoisten asennus- ja huoltohenkilöiden käyttöön.



# SIKKERHETS INFORMASJON

Når ordene ADVARSEL (WARNING) og VIKTIG (CAUTION) blir brukt i manualen og på produkte gjelder det informasjon som har med brukerens sikkerhet å gjøre. Ordene har følgende mening:

ADVARSEL: Tilhørende informasjon viser til forhold som kan resultere i alvorlige skader eller (WARNING) ødeleggelser hvis anvisningene ikke følges nøye.

Tilhørende informasjon forteller deg hvordan du skal unngå feil på utstyret, eller unngå situasjoner som kan resultere i mindre skader. VIKTIG: (CAUTION)

Produkt merkingen og bruksanvisningen bruker internasjonale symboler for å merke punkter som er viktige for brukerens sikkerhet.



Lynet i en triangel advarer brukeren om uisolert "farlig spenning" inne i apparatet, eller tilkoblings terminaler som kan gi støt.



Etter utropstegnet i en triangel følger informasjon som er viktig når det gjelder installasjon, bruk og vedlikehold (service) av apparatet.

ADVARSEL: FOR Å REDUSERE FAREN FOR BRANN ELLER STØT MÅ APPARATET IKKE (WARNING) UTSETTES FOR VANN ELLER FUKTIGHET.

Installasjon av apparatet skal foretas av autorisert installatør etter gjeldende forskrifter. VIKTIG: (CAUTION)



Modifikasjoner og tilleggs informasjon som følger er kun for kvalifiserte installatører eller service personell.



### SÄKERHETS INFORMATION

Orden VARNING (WARNING) och OBSERVERA (CAUTION) vilka används i denna manual och på apparaten, är menade att uppmärksamma viktig säkerhets information. Dessa ord har följande

VARNING: (WARNING)

Information som uppmärksammar på omständigheter som kan resultera i allvarlig personskada eller skada på egendom om instruktionerna ej följs.

OBSERVERA: Information som uppmärksammar på instruktioner om hur skada på utrustning eller hur situationer där lättare personskador kan uppstå undvikes.

Följande internationellt använda ord och symboler används i handboken och på märkninger på produkten för att uppmärksamma användare på viktiga säkerhets instruktioner.



En blixt med pil, innesluten i en triangel, menad att uppmärksamma användare på närvaron av olsolerade "farliga spånningar" i apparaten eller på anslutnings konlakter vilka har tillräcklig styrka för att medföra risk för elektrisk söt.



Ett utropstecken, inneslutet i en triangel, menad att uppmärksamma användare på viktiga installations, handhavande eller underhålls-instruktioner i medföljande dokumentation.

FÖR ATT MINSKA RISKEN FÖR BRAND ELLER ELEKTRISK STÖT, UTSÄTT EJ APPARATEN FÖR FUKT ELLER VÄTSKA.

OBSERVERA: (CAUTION) Installation av denna apparat skall utföras av kvalificerad installatör samt enligt alla gållande lokala bestämmelser.



Eventuella modifierings instruktioner och annan information av teknisk art i denna manual är endast avsedd att användas av kvalificierad installations och service personal.





OBSERVERA: FÖR ATT MINSKA RISKEN FÖR ELEKTRISK STÖT, AVLÄGSNA EJ LOCKET.

INGA AV ANVÄNDARE UTBYTBARA ELLER REPARERBARA

ALL SERVICE PÅ DENNA APPARAT SKALL UTFÖRAS AV KVALIFICIERAD PERSONAL

#### ΠΛΗΡΟΦΟΡΙΕΣ ΑΣΦΑΛΕΙΑΣ

Οι λέξεις ΚΙΝΑΥΝΟΣ (WARNING) και ΠΡΟΣΟΧΗ (CAUTION) που αναφέρονται μέσα στο εγχειρίδιο και στη συσκευή, επικετρώνουν την προσοχή σε σημαντικές πληροφορίες ασφαλείας. Οι λέξεις ανείς έχουν την παρακτά σημασία.

ΚΙΝΔΥΝΟΣ: Η αναγραφόμενη πληροφορία επιστά την προσοχή σας σε καταστάσεις που (WARNING) θα μπορούσαν να έχουν σαν ανοτέλεσμα σοβαφό τραυματισμό ή καταστροφή της ιδιοκτησίας συ ο ισήτείς δεν ακολουθήθούν κατάλληλα.

Η αναγραφόμενη πληροφορία σας καθοδηγεί πώς να προλάβετε καταστροφή του εξοπλισμού ή πώς να αποφύγετε καταστάσεις που θα μπορούσαν να έχουν ως αποτέλεσμα μικροτραυματισμούς αν δεν ακολουθηθούν τα σωστά βήματα.

Στις επιγραφές των προτόντων και στο εγχειρίδιο λειτουργίας, χρησιμοποι αγνωρισμένα σύμβολα, των οποίων ο ορισμός δίνεται παρακάτω έτσι ώστε να υπογραμμιστούν τα μηνύματα ασφαλείας.



Η φωτεινή αναλαμπή με σύμβολο το βέλος, μέσα στο τρίγωνο, έχει σκοπό να επιστήσει την προσοχή του χρήστη, στην ύπαρξη μη- μονωμένης « επικίνδυνης ισχύος ρεύματος » στο εσωτερικό της συσκευής ή στις άκρες σύνδεσης οι οποίες μπορεί να έχουν αρκετό μέγεθος ώστε να περιέχουν κίνδυνο ηλεκτροπληξίας.



Το επεξηγηματικό σημείο, μέσα στο τρίγωνο, έχει σκοπό να επιστήσει την προσοχή του χρήστη στις σημαντικές οδηγίες εγκατάστασης, λειτουργιας και συντήρησης (service) που περιέχονται στα φυλλάδια που συνοδεύουν την συακευή.

ΚΙΝΔΥΝΟΣ : Για να αποφύγετε τον κίνδυνο φωτιάς ή ηλεκτροπληξίας, μην εκθέτετε αυτή τη (WARNING) αυσκευή σε βροχή ή σε υγρασία.

 $\begin{aligned} & \textbf{ΠΡΟΣΟΧΗ}: & \textbf{H} \text{ εγκατάσταση αυτής της συσκευής θα πρέπει να γίνει από εξειδικευμένο άτομο και} \\ & (\textbf{CAUTION}) & \textbf{θα πρέπει να προσαρμόζεται σε όλους τους εφαρμόσιμους τοπικούς κώδικες.} \end{aligned}$ 



Οι τροποποιήστες και οι προϋποθετικές πληροφορίες για τον εξυπλισμό, που αναφέρονται οι αυτό το εγχειρίδιο, προορίζονται για χρήση μόνο από εξειδικευμένα στην εγκατάσταση και στο service, έτομα.



ΠΡΟΣΟΧΗ : ΓΙΑ ΝΑ ΜΕΙΩΣΕΤΕ ΤΟΝ ΚΙΝΔΥΝΟ ΗΛΕΚΤΡΟΠΛΉΞΙΑΣ, ΜΙΓΝ ΜΕΤΑΚΙΝΉΣΕΤΕ ΤΟ ΚΑΛΥΜΜΑ. ΔΕΝ ΠΑΡΕΧΟΝΤΑΙ ΑΝΤΑΛΛΑΚΤΙΚΑ SERVICE ΣΤΟΝ ΧΡΗΣΤΗ

ΓΙΑ SERVICE ΑΝΑΦΕΡΘΕΙΤΕ ΣΤΟ ΡΞΟΥΣΙΟΔΟΤΗΜΕΝΟ ΠΡΟΣΩΠΙΚΟ SERVICE

# INFORMAÇÃO SOBRE SEGURANÇA

As palavras ADVERTÊNCIA (WARNING) e PRECAUÇÃO (CAUTION) neste manual, e no dispositivo, alertam para importantes informações sobre segurança. Estas palavras significam o

ADVERTÊNCIA: Informação relacionada que alerta sobre condições que poderão resultar em (WARNING) lesões sérias ou prejuízo, se as instruções não forem seguidas adequadamentr

PRECAUÇÃO: (CAUTION)

informação relacionada que instrúi como prevenir danos no equipamento ou como evitar condições que poderão resultar em lesões leves, se os passos não forem seguidos adequadamente.

As etiquetas do produto e do manual de operações podem usar os símbolos internacionalmente reconhecidos definidos abaixo para advertir mensagens de segurança.



simbolo do relâmpago com uma seta, dentro de um triângulo, tem o fim de alertar o usuáno a presença de "voltagem perigosa" sem isoleção dentro de caixa isolamento de aparelho ou nos terminais de ligação que podem ter a magnitude suficiente que constitui um risco de choque eléctrico.



ponto de exclamação, dentro de um triangulo, tem o fim de alertar o usuáno sobre instruções importantes de instalação, operação e manutenção (serviços) na literatura que acompanha o aparelho.

ADVERTÊNCIA: PARA REDUZIR O RISCO DE INCÊNDIO OU CHOQUE ELÉCTRICO, (WARNING) NÃO EXPONHA ESTE APARELHO A CHUVA OU HUMIDADE.

PRECAUÇÃO: (CAUTION) A instalação deste aparelho deve ser feita por um profissional qualificado e deve obedecer a todos os códigos locais aplicáveis.



Modificação e informação sobre equipamento adicional citados neste manual são para o uso exclusivo do pessoal gualificado de instalação e manutenção.



PRECAUÇÃO: PARA REDUZIR O RISCO DE CHOQUE ELÉCTRICO, NÃO REMOVA A TAMPA. PARTES INTERNAS NÃO MANTIDAS PELO USUÁRIO ENCAMINHE A MANUTENÇÃO PARA PESSOAL DE SERVIÇOS QUALIFICADO.